



SET VAN LOSSE HAKEN



Omschrijving

- CKS.K1: set met 65 haken: 20 x CKS.60A, 20 x CKS.61A, 5 x CKS.67A, 5 x CKS68A, 5 x CKS.50A, 5 x CKS.51A, 5 x CKS.52A.
- CKS.K2: set met 40 haken: 5 x CKS.45A, 5 x CKS.46A, 5 x CKS.55A, 5 x CKS56A, 10 x CKS.66A, 10 x CKS.67A.
- CKS.K3: set met 65 haken: 20 x CKS.60A, 20 x CKS.61A, 5 x CKS.67A, 5 x CKS68A, 5 x CKS.50A, 5 x CKS.51A, 5 x CKS.52A.



Varianten (3)

Artikelnummer	Artikelnummer fabrikant	L3
41-10150-280	CKS.K1	PZ3
41-10150-281	CKS.K2	
41-10150-282	CKS.K3	